

User Manual

ECO Smart APP Control Recessed LED Downlight

WARNING M

- 1. Switch off power supply before installation / maintenance.
- 2.Switch on after completing installation and examination of the circuit.
- 3. The light must be installed and maintained by professional electrician.
- 4. Input wire diameter ≥0.75mm²
- 5. Warranty will be invalidated for product alteration and improper installation.
- 6. If the light source of the luminaire becomes damaged, the luminaire cannot be fixed or replaced by the user and must be disposed of.
- 7. Increased potential for overheating or fire hazard in the event of compromised clearance distances.





